
Unable to turn on the power when using the battery pack.

Recharge the battery pack.

If the terminal of this unit or the battery pack is dirty, wipe it with a cotton swab or something similar.

If you use any other battery packs besides JVC battery packs, safety and performance cannot be guaranteed. Be sure to use JVC battery packs.

When the battery level is extremely low, this unit does not turn on until it is charged even if it is connected to a computer or AC adapter.