

Playback Menu (Video)

You can delete or look for specific videos.

Setting	Details
DELETE	Deletes unwanted videos.
PROTECT/CANCEL	Protects files from being deleted accidentally.
CLOCK ADJUST	Resets the current time or sets to the local time when using this unit overseas.
ON-SCREEN DISPLAY	Sets whether to show on-screen displays such as icons during playback.