



Protecting Selected Files


Protects or releases protection of the selected files.

Memo :


To select/move cursor towards up/left or down/right, press the button UP/< or DOWN/>.




1 Select the playback mode.




2 Press MENU.



3 Select "PROTECT/CANCEL" and press OK.





4 Select "FILE SELECT" and press OK.



- To exit, press MENU, select "YES" and press OK.

5 Select the files to protect or release protection of and press OK.



- A protect mark **On** appears on the selected file.
To remove the protect mark **On**, press OK again.
- To move to the next page on the index screen, slide along the  (zoom) lever.
- If the transmission mode of Eye-Fi Helper is set to "Share Selected Files Only" or "Transmit Selected Files Only",  will be displayed.

6 After selecting all the files to protect or release protection of, press MENU.

7 Select "YES" and press OK.

- To cancel the protection, select "NO" and press OK.