Grip Adjustment



- 1 Open the lever on the strap lock
- 2 Adjust the length of the belt
- 3 Close the lever

Caution : -

- Be sure to fasten the grip belt properly. If the belt is loose, this unit may drop and result in injuries or damages.