
Adjusting Focus Manually

Set this when the focus is not clear in Intelligent Auto or when manual focusing is desired.


1 Tap "MENU".



2 Tap "FOCUS".




- \bullet Tap \wedge or \vee to move upward or downward for more selection.
- ullet Tap imes to exit the menu.
- Tap [♠] to return to the previous screen.
- 3 Tap "MANUAL".



4 Adjust the focus.



- Tap ▲ to focus on a distant subject.
- 5 Tap "SET" to confirm.



When focus is confirmed, the focusing frame disappears and ▲ and ▲ are displayed. (The icons may appear blinking.)

Memo:

 A subject that is focused at the telephoto (T) end remains in focus when it is zoomed out to the wide angle (W) end.