## **CLOCK ADJUST**

Resets the current time or sets to the local time when using this unit overseas. Operating Details