GAIN UP

Makes the subject appear bright automatically when recording in dark places.

| Setting | Details |
|-----------------------|--|
| OFF | Deactivates the function. |
| ON | Electrically brightens the scene when it is dark. |
| AUTO SLOW- SHUTTER | Automatically brightens the scene when it is dark. |

Memo:

- Although "AUTO SLOW-SHUTTER" brightens the scene more than "AGC", movements of the subject may become unnatural.
- Setting can be adjusted separately for still images.

Displaying the Item

Select video mode.



2 Tap • to select the recording mode.



- The mode changes between recording and playback with every tap.
- 3 Tap "MENU".



4 Tap "GAIN UP".

