


Front**1** Lens Cover

- Do not touch the lens and lens cover.
- Do not cover the lens with your fingers during recording.

2 Light (GZ-HM650/GZ-HM670/GZHM690)

- Turn on the light when shooting in dark places.

3 Stereo Microphone

- Do not cover the microphone with your fingers during video recording.