



## Adjusting Focus Manually

Set this when the focus is not clear in Intelligent Auto or when manual focusing is desired.

- 1 Tap "MENU".




- 2 Tap "FOCUS".




- Tap  $\wedge$  or  $\vee$  to move upward or downward for more selection.
- Tap  $\times$  to exit the menu.
- Tap  $\hookrightarrow$  to return to the previous screen.

- 3 Tap "MANUAL".




- 4 Adjust the focus.



- Tap  $\blacktriangle$  to focus on a distant subject.
- Tap  $\blacktriangle$  to focus on a near subject.

- 5 Tap "SET" to confirm.



- When focus is confirmed, the focusing frame disappears and  $\blacktriangle$  and  $\blacktriangle$  are displayed. (The icons may appear blinking.)

**Memo :** \_\_\_\_\_

- A subject that is focused at the telephoto (T) end remains in focus when it is zoomed out to the wide angle (W) end.