

---

**BACK UP menu does not disappear.**

While the USB cable is connected, the "BACK UP" menu is displayed.