

The battery depletes even when the AC adapter is connected.

Please use a JVC AC adapter (AC-V11).