

HDMI OUTPUT

Sets the output from the HDMI connector of this unit when it is connected to a TV.


Setting	Details
AUTO	It is recommended to select “AUTO” usually.
576p	Select this when the video is not output in “AUTO” correctly.

Displaying the Item

1 Tap “MENU”.



2 Tap “⚙️”.



3 Tap “HDMI OUTPUT”.

