


**LIGHT (GZ-HM445/GZ-HM650/GZ-HM670)**


Turns on/off the light.

Setting	Details
OFF	Does not light up.
AUTO	Lights up automatically when the surrounding is dark.
ON	Lights up at all times.

**Displaying the Item**

1 Select video mode.



2 Tap  to select the recording mode.



- The mode changes between recording and playback with every tap.

3 Tap “MENU”.



4 Tap “LIGHT”.

