

The language on the display changed.

It may occur when you connect this unit to a TV with different language setting using an HDMI mini cable.