

UNABLE TO COMMUNICATE WITH THE Bluetooth DEVICE

Make sure that there are no obstacles between the Bluetooth-compliant device and the camcorder.

Check the registered device and register again.

Refer to the instruction manual of the connected device.