



Main Menu for Still Image Recording

You can adjust various settings, such as brightness and white balance, to suit the subject or purpose. You can also change settings such as picture quality and gain.

- 1 Select still image mode.



- 2 Tap "MENU".



Setting	Details
SCENE SELECT	Settings to suit the shooting condition can be selected. *Displayed only in the manual recording mode.
FOCUS	Focus can be adjusted manually. *Displayed only in the manual recording mode.
FOCUS ASSIST	Focused subject is outlined in color for more precise focus. *Displayed only in the manual recording mode.
FOCUS ASSIST COLOR	Sets the color of the outline of a focused object when Focus Assist is used. *Displayed only in the manual recording mode.
BRIGHTNESS ADJUST	Adjusts the overall brightness of the screen. *Displayed only in the manual recording mode.
SHUTTER SPEED	Shutter speed can be adjusted. *Displayed only in the manual recording mode.
APERTURE PRIORITY	Adjusts the aperture value. *Displayed only in the manual recording mode.
WHITE BALANCE	Adjusts the color according to the light source. *Displayed only in the manual recording mode.
BACKLIGHT COMP.	Corrects the image when the subject appears dark due to backlight. *Displayed only in the manual recording mode.
TELE MACRO	Enables close-up shots when using the telephoto (T) end of the zoom. *Displayed only in the manual recording mode.

Menu Settings

Setting	Details
TOUCH PRIORITY AE/AF	Automatically adjusts focus and brightness based on the subjects' faces or selected area.
FLASH	Sets the flash to use.
SELF-TIMER	Use this when taking a group photo.
GAIN	Enables selection of the ISO level.
AUTO REC	Enables the unit to record still images automatically by sensing the changes in brightness within the red frame displayed on the LCD monitor.
SHUTTER MODE	Continuous shooting settings can be adjusted.
CONT. SHOOTING SPEED	Sets the speed for continuous shooting.
SMILE SHOT	Automatically captures a still image upon detection of a smile.
SMILE%/NAME DISPLAY	Sets the items to display when faces are detected.
FACE REGISTRATION	Registers the faces of people who are often shot with this unit.
IMAGE SIZE	Sets the image size (number of pixels) for still images.
USER BUTTON SETTING	Assigns a frequently used function to the USER button.