


Verifying the Accessories

If any of the items are missing or defective, consult your JVC dealer or the nearest JVC service center.

Illustration	Description
	<p>AC Adapter AC-V11U (for GZ-HM860)</p> <ul style="list-style-type: none"> Connects to this unit to charge the battery pack. It can also be used when recording or playing back videos indoors.
	<p>AC Adapter AP-V30U (for GZ-HM960)</p> <ul style="list-style-type: none"> Connects to this unit to charge the battery pack. It can also be used when recording or playing back videos indoors.
	<p>Battery Pack BN-VG114U</p> <ul style="list-style-type: none"> Attaches to this unit to supply power.
	<p>Remote Control RM-V760U</p> <ul style="list-style-type: none"> Operates certain functions from a distance.
	<p>HDMI Mini Cable</p> <ul style="list-style-type: none"> Connects this unit to a TV to play back recorded images on the TV in a better quality.
	<p>AV Cable</p> <ul style="list-style-type: none"> Connects this unit to a TV to play back recorded images on the TV.
	<p>USB Cable (Type A - Mini Type B)</p> <ul style="list-style-type: none"> Connects this unit to a computer.
	<p>Core Filter (Large)×2 (for AV Cable and optional Component Cable) Core Filter (Small) (for AC Adapter)</p> <ul style="list-style-type: none"> The core filter reduces interference when this unit is connected to other devices.

Getting Started



Basic User Guide

- Read well and keep in a safe place where it can be accessed easily when necessary.

Memo :

- SD cards are sold separately.
 - When using the AC adapter overseas, please prepare a commercially available converter plug for the country or region of visit.
-