


ERASE ALL DATA

Execute this process when disposing of this unit or passing it to another person.

1 Tap "MENU".



2 Tap "⚙️".



3 Tap "ERASE ALL DATA".



4 Tap "YES".



- After deleting is complete, tap "OK".

Caution : _____

- Connect the AC adapter when erasing all data on the built-in memory. Erasing cannot be performed if the AC adapter is not connected.

Memo : _____

- Repeat the process to make data restoration even more difficult.