

Operating the Menu

There are three types of menus in this unit.

- Main menu - Menu that contains all the items specific to the video recording, still image recording, video playback, and still image playback modes respectively.
- **⚙** ("COMMON") menu in the main menu - Menu that contains all common items in the video recording, still image recording, video playback, and still image playback modes.
- **S** (face short cut) menu - Menu that picks up the face-related functions in the main menu in either the video or still image recording mode.