

## Operating the Face Short Cut Menu

You can configure various settings of face-related functions in either the video or still image recording mode using the face short cut menu.

- 1 Tap "S" in the video or still image recording mode.



- 2 Tap the desired menu and setting.

- Face Short Cut Menu During Video Recording Mode



- Face Short Cut Menu During Still Image Recording Mode



### Memo :

- To exit the screen

Tap "X" (quit).

- To display the help file

Tap "?" (help) and tap the item.