





Interior



- 1** Speaker
 - Outputs audio sound during video playback.
- 2** USB Connector
 - Connects to computer using a USB cable.
- 3** HDMI Connector
 - Connects to an HDMI TV.
- 4** USER Button
 - Activates preset functions.
- 5**  /  (Video/Still Image) Button
 - Switches between video and still image modes.
- 6**  / INFO (Power/Information) Button
 - Recording: Displays the remaining time (for video only) and battery power.
 - Playback: Displays file information such as recording date.
 - Press and hold to turn the power on/off while the LCD monitor is opened.
- 7** i.AUTO Button
 - Switches between Intelligent Auto and Manual modes.