
The remote control does not work. (for GZ-HM960)

Replace the battery.

Set "REMOTE" in the "COMMON" menu to "ON".

The remote control may not operate outdoors or in places exposed to strong light.