Unable to delete folder in USB external hard disk drive.

Delete the folder using a computer. (When files are added or folders moved/renamed with a computer, they cannot be deleted on this unit.)