


Formatting the USB External Hard Disk Drive

All files on the external hard disk drive can be deleted.


Caution :

- All data on the external hard disk drive will be deleted when it is formatted. Copy all files on the card to a PC before formatting.


- 1 Select video or still image mode.



- 2 Tap "FORMAT".



- 3 Tap "YES".



- After formatting, tap "OK".