

SHUTTER MODE


Continuous shooting settings can be adjusted.

Setting	Details
RECORD ONE SHOT	Records one still image.
CONTINUOUS SHOOTING	Records still images continuously while the SNAPSHOT button is pressed.

- Memo :**
- The continuous shooting speed can be changed.
  - Performing continuous shooting while video recording is in progress switches the mode to “LOW SPEED” temporarily.
  - The size of the still image that is captured in the video mode is 1,920 x 1,080.
  - Some SD cards may not support continuous shooting.
  - The continuous shooting speed will drop if this function is used repeatedly.

Displaying the Item

- 1 Select video mode.



- 2 Tap “MENU”.



- 3 Tap “SHUTTER MODE”.

