


Dubbing Files to a Disc by Connecting to a DVD Recorder

You can dub videos in standard quality by connecting to a DVD recorder.

- Refer also to the instruction manuals of the TV and DVD recorder.

1 Connect to a DVD recorder.




* The AC adapter shown in the illustration is AC-V10M.

① Connect using the provided AV cable.

② Connect the AC adapter to this unit.

- This unit powers on automatically when the AC adapter is connected.
- Be sure to use the supplied JVC AC adapter.

2 Tap to select the playback mode.



- The mode changes between recording and playback with every tap.

3 Prepare the TV/DVD recorder for recording.

- Switch to a compatible external input.
- Insert a disc (DVD-R, etc.) into the DVD recorder.

4 Prepare this unit for playback.

- Set "VIDEO OUTPUT" in the "COMMON" menu to the aspect ratio ("4:3" or "16:9") of the connecting TV.

5 Start recording.

- Start playback on this unit and press the record button on the recorder.
- After playback is complete, stop the recording.