Cannot find a recorded file.

Cancel the date search function.

Change the playback media by tapping *SD on the touch screen.