


ZOOM MIC

Sets the zoom microphone.


Setting	Details
OFF	Deactivates the zoom microphone.
ON	Records audio sounds in the same direction as the zoom operation.

Displaying the Item

- 1 Select video mode.



- 2 Tap “MENU”.



- 3 Tap “ZOOM MIC”.

