

شارژ کردن بسته باتری در سایر کشورها

شکل خروجی برق در کشورها و مناطق مختلف فرق می کند.
برای شارژ بسته باتری، به یک مبدل پریز برای تطابق با شکل خروجی نیاز دارید.

A	B	BF	C	O
				

North America		Europe		Oceania		Middle East	
United States	A	Iceland	C	Australia	O	Israel	C
Canada	A	Ireland	C	Guam	A	Iran	C
Mexico	A	United Kingdom	B BF	Tahiti	C	Kuwait	B C
Asia		Italy	C	Tonga	O	Jordan	B BF
		Austria	C	New Zealand	O	Africa	
		Netherlands	C	Fiji	O		
		Canary Islands	C	Latin			
		Greece	C	Argentina	O		
Indonesia	C	Switzerland	C	Colombia	A	Guinea	C
Singapore	B BF	Sweden	C	Jamaica	A	Kenya	B C
Sri Lanka	B C BF	Spain	A C	Chile	B C	Zambia	B BF
Thailand	A BF C	Denmark	C	Haiti	A	Tanzania	B BF
South Korea	A C	Germany	C	Panama	A	Republic of South Africa	B C BF
China	A B BF C O	Norway	C	Bahamas	A	Mozambique	C
Japan	A	Hungary	C	Puerto Rico	A	Morocco	C
Nepal	C	Finland	C	Brazil	A C		
Pakistan	B C	France	C	Venezuela	A		
Bangladesh	C	Belgium	C	Peru	A C		
Philippines	A BF O	Poland	B C				
Vietnam	A C	Portugal	B C				
Hong Kong Special		Romania	C				
Administrative Region	B BF						
Macau Special							
Administrative Region	B C						
Malaysia	B BF C						