


Front

- 1** Lens Cover
 - Do not touch the lens and lens cover.
 - Do not cover the lens with your fingers during video recording.
- 2** Stereo Microphone
 - Do not cover the microphone with your fingers during video recording.
- 3** Camera Sensor
 - Do not cover the sensor with your fingers during video recording.
- 4** POWER/CHARGE Lamp
 - Lights up: Power "ON"
 - Blinks: Charging in progress
 - Goes out: Charging finished
- 5** ACCESS Lamp
 - Recording or playback is in progress when the lamp lights up or blinks.
 - Do not remove the battery pack, AC adapter, or microSD card.