






## Interior



- 1** Speaker
  - Outputs audio sound during video playback.
- 2**  (Play) Button
  - Switches between the recording and playback modes.
- 3**  /  (Video/Still Image) Button
  - Switches between video and still image.
- 4** UPLOAD Button
  - Recording: Takes videos in YouTube™ format.
  - Playback: Changes the video to YouTube™ format.
- 5**  (Power/Info) Button
  - Recording: Displays the remaining time (for video only) and battery power.
  - Playback: Displays file information such as recording date.
  - Press and hold to turn the power on/off while the LCD monitor is opened.
- 6** AV Terminal
  - Connects to a TV.
- 7** COMPONENT Terminal
  - Connects to a TV.
- 8** HDMI Terminal
  - Connects to an HDMI TV.