Editing Playlists

You can change the content of a created playlist.

Select the playback mode.



2 Select video mode.



3 Touch (em) to display the menu.



4 Select "EDIT PLAYLIST" and touch @.



5 Select "EDIT" and touch ok.



6 Select the playlist you want to edit and touch .



7 Select the file to add to playlist and touch ®.



• Touch "CHECK" to check the selected video.

8 Select the insertion point and touch @.



- The selected videos are added to the playlist on the right.
- To delete a video from the playlist, touch "→" to select the video and touch ®.
- Repeat steps 7-8 and arrange the videos in the playlist.



10 Select "SAVE AND THEN QUIT" and touch @s.

