No date/time display.

Set "ON-SCREEN DISPLAY" in the menu accordingly.
Set "DISPLAY ON TV" in the menu to "ON".