

---

**SCENE QUANTITY EXCEEDED LIMIT**

- (1) Move the files or folders to a PC or other device. (Back up your files.)
- (2) Select "FILE + MANAGEMENT NO" in "FORMAT HDD" or "FORMAT SD CARD" of the media settings menu. (All data on the HDD or microSD card will be deleted.)