## **Scene Selection**

Common scenes that are often encountered can be recorded with the most suitable settings.

1 Touch (10) to display the menu.



2 Select "MANUAL SETTING" and touch @.



3 Select "SCENE SELECT" and touch ®.



4 Select the scene and touch .



Setting	Effect
M NIGHT EYE	Increases gain and brightens the scene automatically when the surrounding is dark.  To prevent camera shake, use a tripod.  OFF  ON
■ SPOTLIGHT	Prevents the human subject from appearing too bright under light.  OFF  ON

<sup>\*</sup>The image is only an impression.