

DEMO MODE

Starts playback of the demo mode which introduces the features of this unit.

| Setting | Details |
|---------|---|
| OFF | Deactivates the function. |
| ON | Plays a demonstration of the special features of this unit. |

Displaying Demo Mode

- 1 Remove the battery pack and SD card.
- 2 Connect the AC adapter.
- 3 Open the LCD monitor and turn on the power.


- Demonstration starts playing after 3 minutes.
- To stop playback, touch **OK**.

Memo : _____

- This mode is not available in the playback mode.

Displaying the Item

- 1 Touch **Menu** to display the menu.



- 2 Select "BASIC SETTINGS" and touch **OK**.



- 3 Select "DEMO MODE" and touch **OK**.

