

Carga de la batería en el extranjero

La forma del tomacorriente varía según el país y la región.
Para cargar la batería, necesita un enchufe adaptador que coincida con la forma del tomacorriente.

A	B	BF	C	O
				

North America		Europe		Oceania		Middle East	
United States	A	Iceland	C	Australia	O	Israel	C
Canada	A	Ireland	C	Guam	A	Iran	C
Mexico	A	United Kingdom	B,BF	Tahiti	C	Kuwait	B,C
Asia		Italy	C	Tonga	O	Jordan	B,BF
India	B,C,BF	Austria	C	New Zealand	O	Africa	
Indonesia	C	Netherlands	C	Fiji	O	Algeria	A,B,BF,C
Singapore	B,BF	Canary Islands	C	Latin		Egypt	B,BF,C
Sri Lanka	B,C,BF	Greece	C	Argentina	O	Guinea	C
Thailand	A,BF,C	Switzerland	C	Colombia	A	Kenya	B,C
South Korea	A,C	Sweden	C	Chile	B,C	Zambia	B,BF
China	A,B,BF,C,O	Spain	A,C	Jamaica	A	Tanzania	B,BF
Japan	A	Denmark	C	Peru	A,C	Republic of South Africa	B,C,BF
Nepal	C	Germany	C	Panama	A	Mozambique	C
Pakistan	B,C	Norway	C	Bahamas	A	Morocco	C
Bangladesh	C	Hungary	C	Puerto Rico	A		
Philippines	A,BF,O	Finland	C	Brazil	A,C		
Vietnam	A,C	France	C	Venezuela	A		
Hong Kong Special		Belgium	C				
Administrative Region	B,BF	Poland	B,C				
Macau Special		Portugal	B,C				
Administrative Region	B,C	Romania	C				
Malaysia	B,BF,C						