


Interior



- 1** Speaker
 - Outputs audio sound during video playback.
- 2** (Play) Button
 - Switches between the recording and playback modes.
- 3** (Video/Still Image) Button
 - Switches between video and still image.
- 4** UPLOAD Button
 - Recording: Takes videos in YouTube™ format.
 - Playback: Changes the video to YouTube™ format.
- 5** (Power/Info) Button
 - Recording: Displays the remaining time (for video only) and battery power.
 - Playback: Displays file information such as recording date.
 - Press and hold to turn the power on/off while the LCD monitor is opened.
- 6** AV Terminal
 - Connects to a TV.
- 7** COMPONENT Terminal
 - Connects to a TV.
- 8** HDMI Terminal
 - Connects to an HDMI TV.