
When connecting to the HDMI mini cable, the image or sound does not appear on the TV properly.

The image or sound may not appear on the TV properly depending on the TV connected. In such cases, perform the following operations. (1)

Disconnect the HDMI mini cable and connect it again. (2) Turn off and on this unit again.