


Setting White Balance

You can set the color tone to suit the light source.

- 1 Touch  to display the menu.



- 2 Select “MANUAL SETTING” and touch .



- 3 Select “WHITE BALANCE” and touch .



- 4 Select the desired setting and touch .



Setting	Details
AUTO	Adjusts automatically to the natural colors.
MWB	Use this when the problem of unnatural colors is not resolved.
FINE	Set this when shooting outdoors on a sunny day.
CLOUD	Set this when shooting on a cloudy day or inside a shade.
HALOGEN	Set this when shooting under illumination such as a video light.

Using MWB

- 1 Hold a sheet of plain white paper in front of the lens so that the white paper fills the screen.
- 2 Select “MWB” and keep touching .
- The cursor blinks.
- 3 Release  after the menu disappears.