

شارژ کردن بسته باتری در سایر کشورها

شکل خروجی برق در کشورها و مناطق مختلف فرق می کند.
برای شارژ بسته باتری، به یک مبدل پریز برای تطابق با شکل خروجی نیاز دارید.

A	B	BF	C	O
				
				

North America	Europe	Oceania	Tyukintou
United States A	Iceland C	Australia O	Israel C
Canada A	Ireland C	Guam A	Iran C
Mexico A	United Kingdom B,BF	Tahiti C	Kuwait B,C
Asia	Italy C	Tonga O	Jordan B,BF
India B,C,BF	Austria C	New Zealand O	Africa
Indonesia C	Netherlands C	Fiji O	Algeria A,B,BF,C
Singapore B,BF	Canary Islands C	Latin	Egypt B,BF,C
Greece C	Switzerland C	Argentina B,F,C,O	Guinea C
Sri Lanka B,C,BF	Sweden C	Colombia A	Kenya B,C
Thailand A,BF,C	Spain A,C	Jamaica A	Zambia B,BF
South Korea A,C	Denmark C	Chile B,C	Tanzania B,BF
China A,B,BF,C,O	Germany C	Haiti A	Republic of South Africa B,C,BF
Nepal C	Norway C	Panama A	Mozambique C
Pakistan B,C	Hungary C	Bahamas A	Morocco C
Bangladesh C	Finland C	Puerto Rico A	
Philippines A,BF,O	France C	Brazil A,C	
Vietnam A,C	Belgium C	Venezuela A	
Hong Kong Special B,BF	Poland B,C	Peru A,C	
Administrative Region	Portugal B,C		
Macao Special B,C	Romania C		
Administrative Region			
Malaysia B,BF,C			