


Setting Shutter Speed (GZ-HD620)

You can set the shutter speed to suit the type of subject.

1 Touch  to display the menu.



2 Select "MANUAL SETTING" and touch .



3 Select "SHUTTER SPEED" and touch .



4 Select "MANUAL" and touch .



5 Select the shutter speed with the slider.



- Shutter speed can be set from 1/2 to 1/4000.
- Slide upward to increase the shutter speed.
- Slide downward to decrease the shutter speed.

6 Touch  to confirm.



Memo:

- It is recommended to use a tripod when recording with a slow shutter speed.