LANGUAGE

The language on the display can be changed.

1 Touch (em) to display the menu.



2 Select "DISPLAY SETTINGS" and touch @.



3 Select "LANGUAGE" and touch .



4 Select the desired language and touch 68.

