CHECK LENS COVER (GZ-HD510/GZ-HD500 only)

Appears for 5 seconds after power is turned on, if the lens cap is attached or when it is dark.