




SELF-TIMER

Use this when taking a group photo.


Setting	Details
OFF	Deactivates the self-timer.
2SEC	Starts recording 2 seconds after the SNAPSHOT button is pressed.
10SEC	Starts recording 10 seconds after the SNAPSHOT button is pressed. This setting is suitable for taking group photos.
FACE DETECTION	Detects faces when the SNAPSHOT button is pressed. Recording starts 3 seconds after the face of the photographer is detected. (1) Faces are detected  (2) Face of photographer is detected <p>Photographer</p> 

Displaying the Item

1 Select still image mode.



2 Touch  to display the menu.



3 Select "SELF-TIMER" and touch .

