
Images do not appear on the TV properly.

Disconnect the cable and connect again.

Turn off and on this unit again.