
Common Recording Indications



- 1 Recording Mode
- 2 Effect
- 3 Scene Select
- 4 Auto REC
- 5 White Balance
- **6** Light
- 7 Quick Review
- 8 Zoom
- 9 Media
- 10 Monitor Backlight
- 11 Metering Area "SPOT" O
- 12 Focus Assist
- 13 Battery Indicator
- 14 Date/Time
- 15 Drop Detection
- 16 Focus
- 17 Tele Macro
- 18 Backlight Compensation
- D: Face Priority AE/AF
- 19 Brightness
- 20 Shutter Speed