


Deleting Folders in the USB External Hard Disk Drive

- 1 Select video or still image mode.



- 2 Select "DELETE" and touch .



- 3 Select the desired folder and touch .



- 4 Select "DELETE" and touch .



- After deleting, touch .