Adjusting Brightness

You can adjust the brightness to your preferred level.

1 Touch ⊕ to display the menu.

2 Select "MANUAL SETTING" and touch ⊛.

3 Select "BRIGHTNESS ADJUST" and touch ⊛.

4 Select "MANUAL" and touch ⊛.

5 Select the brightness value with the slider.

● Compensation range during video recording: -6 to +6

● Compensation range during still image recording: -2.0 to +2.0

● Slide upward to increase the brightness.

● Slide downward to decrease the brightness.

6 Touch ⊛ to confirm.