

Carga de la batería en el extranjero

La forma del tomacorriente varía según el país y la región.

Para cargar la batería, necesita un enchufe adaptador que coincida con la forma del tomacorriente.

A	B	BF	C	O
				
				

North America	Europe	Oceania	Tyukintou
United States A	Iceland C	Australia O	Israel C
Canada A	Ireland C	Guam A	Iran C
Mexico A	United Kingdom B.BF	Tahiti C	Kuwait B.C
Asia	Italy C	Tonga O	Jordan B.BF
India B.C.BF	Austria C	New Zealand O	
Indonesia C	Netherlands C	Fiji O	Africa
Singapore B.BF	Canary Islands C		Algeria A.B.BF.C
Sri Lanka B.C.BF	Greece C	Latin	Egypt B.BF.C
Thailand A.BF.C	Switzerland C	Argentina B.F.C.O	Guinea C
South Korea A.C	Sweden C	Colombia A	Kenya B.C
China A.B.BF.C.O	Spain A.C	Jamaica A	Zambia B.BF
Nepal C	Denmark C	Chile B.C	Tanzania B.BF
Pakistan B.C	Germany C	Haiti A	Republic of South Africa B.C.BF
Bangladesh C	Norway C	Panama A	
Philippines A.BF.O	Hungary C	Bahamas A	Mozambique C
Vietnam A.C	Finland C	Puerto Rico A	Morocco C
Hong Kong Special	France C	Brazil A.C	
Administrative Region B.BF	Belgium C	Venezuela A	
Macau Special	Poland B.C	Peru A.C	
Administrative Region B.C	Portugal B.C		
Malaysia B.BF.C	Romania C		